

Interfacing The MCP23016 I/O Expander With The PIC16F877A

Author: Abdelwahab Fassi-Fihri Microchip Technology Inc.

INTRODUCTION

This application note describes how to use a PIC16F877A as an I^2C^{TM} master to communicate with the Microchip MCP23016 I^2C I/O Expander slave device.

An I/O Expander device is used to increase the I/O capability of a microcontroller (refer to Figure 1). A microcontroller's I^2C port can be used as a communication channel with MCP23016(s) to expand the microcontroller's I/O count. By using two I^2C pins (and one general-purpose I/O pin, if using the interrupt capability of the MCP23016), 16 to 128 general-purpose I/Os can be gained. The MCP23016 has three address pins which can be used to provide unique addresses for up to eight devices.

Each device attached to the I^2C bus must be assigned a unique address unless all devices (with the same address) are receiving the same data and do not transmit any data. When the master initiates a data transfer, the address of the slave <u>device</u> is transmitted. Within the address, the LSb (R/W bit) specifies whether the master reads from, or writes to, the slave. For write operations, a series of bytes would be transmitted from the master. For read operations, the master waits for the bus to be free (i.e., SCL line not pulled low) and then clocks the data to be received from the slave.

What can you do with an I/O Expander?

An I/O Expander can also be used to monitor switches and/or sensors, drive LEDs and/or relays, as well as other general-purpose I/O functions. An I/O Expander can have several uses in a variety of applications. Typical applications include high-side MOSFET loadswitch drivers in power-management systems and keyboards.

The I²C Bus Specification

This application note does not discuss the I^2C specification in detail. Refer to the following documents (www.microchip.com) for more information on the I^2C specification and implementation:

- AN578, "Use of the SSP Module in the I²C Multi-Master Environment", DS00578.
- AN735, "Using the PICmicro MSSP Module for Master I²C Comm", DS00735.
- AN736, "An I²C Network Protocol For Environmental Monitoring", DS00736.
- MCP23016 Datasheet, DS20090.

For complete I^2C bus specifications, refer to the Philips[®]/Signetics[®] document, "The I^2C Bus and How to Use It".



INITIATING AND TERMINATING DATA TRANSFER

During times of no data transfer (idle time), both the SCL and SDA lines are pulled high via pull-up resistors. A master device takes control of the bus during bus idle by generating a START condition. A START is defined as a high-to-low transition of SDA when SCL is high. When the master has completed all data, it releases the bus by generating a STOP condition. A STOP is defined as a low-to-high transition of SDA while SCL is high. Because the START and STOP conditions are defined as transitions of the SDA when the SCL line is high, the SDA line can only change when SCL is low during the actual data transmission. Figure 2 shows the relationship between SCL and SDA for the various conditions. A REPEATED-START condition (Figure 3) is generated by the master to maintain control of the bus while switching between write mode and read mode and/or while in multi-master environments. To generate a REPEATED-START, both SDA and SCL start low. SDA is then asserted high, followed by SCL being asserted high. Finally, SDA is asserted low while SCL is high.

FIGURE 2: START AND STOP CONDITIONS



FIGURE 3:





Addressing the MCP23016 I/O Expander

I²C devices can be addressed in two different modes: 10-bit addressing or 7-bit addressing modes. The MCP23016 uses the 7-bit addressing, as shown in Figure 4 and Figure 5. Therefore, this application note will only be using the 7-bit addressing mode. To understand how the MCP23016 works, refer to the MCP23016 datasheet, DS20090.



THE 7-BIT ADDRESS FOR THE MCP23016



FIGURE 5:

THE 7-BIT ADDRESS FORMAT



WRITING TO THE MCP23016 I/O EXPANDER

During write mode (Figure 6), all data is transmitted as bytes, with no limit to the number of bytes transmitted per data transfer. After each byte, the slave (receiver) generates an acknowledge bit (ACK) by pulling the SDA line low. If a slave doesn't acknowledge the slave address or received data, the master aborts the transfer. Whether the ACK bit is generated or not, the SDA line must be released by the slave so the master can generate the STOP condition. The protocol used to communicate with the MCP23016 is simple for a write operation. First, a START condition is generated, followed by the slave address with the LSb=0 (R/W=0). The command byte is then transmitted (the command byte is like an address pointer. It gives the address of the register to be written to). This is followed by the first data byte which is written to the first byte of the register pair addressed by the command byte. Finally, the second data byte is written to the second byte of the register pair. This can be followed by more data byte pairs or by a STOP condition.

Although writing data from the master to the slave is very simple, some safeguards need to be implemented. To ensure proper functioning of the device, follow the master writing sequence flowchart, as shown in Figure 7.

Note:	A 12 µs delay is required after every 9th clock on SCL to allow the MCP23016 time					
	to process the contents on SDA. This is in					
	addition to any SCL hold times the					
	MCP23016 may require (See Figure 6).					





- Note 1: The master needs to wait for I²C bus idle to indicate that the MSSP module has finished its last task. The SSPIF interrupt could be used instead of the wait for idle (the interrupt is not used in this application note).
 - 2: A 12 µs delay is inserted, as stated in the MCP23016 datasheet. If a 12 µs delay is not inserted, it can lead to the malfunction of the MCP23016. This could be caused either by receiving false data or by locking up the I²C bus all together.
 - 3: A NACK is issued to the slave-transmitter that the master wants to stop receiving data from it. If a NACK is not received by the slavetransmitter, it will not reset the internal state machine following a STOP or a REPEATED-START. This would cause the MCP23016 to lock up.

READING FROM THE MCP23016 I/O EXPANDER



When the master is receiving data during read mode (Figure 8), it generates an acknowledge signal for each received byte of data except for the last byte. To signal the end of data to the slave-transmitter, the master generates a "not acknowledge" (NACK) condition (ACK=1). This is very important for proper functioning of read mode. The slave then releases the SDA line so the master can generate the STOP condition. If the slave needs to delay the transmission of the next byte, it may hold the SCL line low to force the master into a wait state. Data transfer continues when the slave releases the SCL line. This allows the slave to move the received data or fetch the data it needs to transfer before allowing the clock to start again. This wait state technique can also be implemented at the bit level.

The protocol used to communicate with the MCP23016 for a read operation is as follows: A START condition is generated, followed by the slave address with the LSb=0 (R/W=0 to indicate a write condition). The command byte is then transmitted (the command byte is like an address pointer. It gives the address of the register to read from). This is followed by a REPEATED-START condition. The slave address is transmitted again but with the LSb=1 (R/W=1 to indicate a read condition). The master waits for the slave to release the SCL before beginning to clock the first data byte. After receiving the first data byte, the master waits again for the SCL to be released before clocking the second data byte. This can be followed by more data bytes as long as the master keeps acknowledging after each data byte. At the end of the last data byte, the master needs to generate a NACK before issuing a STOP or **REPEATED-START** condition.

Although reading data from the slave by the master is very simple, some safeguards need to be implemented.

To ensure proper functioning of the device, follow the master reading sequence flowchart shown in Figure 9.





INTERFACE CODE

For this application, the PIC16F877A provides an MSSP module for I^2C communication.

The firmware code for this application is written in C using the Hi-Tech PICC[™] C Compiler and is available on Microchip's website (www.microchip.com). Table 1 provides a list of source code files.

TABLE 1:MASTER I²C 'C' SOURCECODE FILES

Filename	Description		
16chaser.c	Main code loop and interrupt handler.		
delay.c	Delay routines.		
delay.h	Delay function prototypes.		
l ² Crxtx.h	Hardware I ² C master routines for PIC16F877A.		
pic.h	Required by compiler for SFR decla- rations.		
l ² Crxtx.h	Hardware I ² C master function prototypes		

The CCP2 module in the PIC16F877A is being used to generate an interrupt on every falling edge of the MCP23016 interrupt pin.

Master implementation

The master device (PIC16F877A), upon completion of the internal power-up cycle, performs some basic peripheral and variable initialization. The ADC module is disabled, I/O ports are configured, the MSSP module is configured for master I²C mode with 400 kHz baud rate and slew rate is enabled and the CCP2 module is configured to interrupt on the falling edge. Once the peripheral initialization is completed, peripheral and global interrupts are enabled. A small delay is then introduced to allow the MCP23016 to complete its internal power-up cycle. The I/O Expander is then initialized by setting the ports to predefined values, changing the direction of the port pins and changing the polarity. The main code execution loop is then entered (see Figure 11). In the main loop, the Check_CCP_status() routine is called, followed by a small delay. The variables "i" and "j" are transmitted to the MCP23016. They are then shifted one to the right and the other to the left and vice versa to get an LED chaser light effect.

When an interrupt occurs on the CCP2 module, the CCP2IF bit is cleared and a software flag is set (see Figure 12). The software flag is used in case of an interrupt occurring while the master is transmitting or receiving, the task being performed will finish before servicing the interrupt.

Check_CCP_status() checks if the software interrupt has been set. If the flag is not set, the code goes back to "main". If the flag is set, the flag is cleared and *GetNewValue()* is called (see Figure 13). *GetNewValue()* is a function that reads the MCP23016 port values and then displays them on the LEDs (see Figure 14). Then it checks if the interrupt pin is still low. If low, the code reads the MCP23016 port values again. If high, the code goes back to the main loop. Refer to Table 2 for a description of all the functions used in the source code.

Functions	lanut	0tmt	Description
Functions	Input	Output	Description
I ² C_init()	None	None	Initializes the SSP module for I ² C master
			communication.
I ² C_waitForIdle()	None	None	Waits for the I ² C bus to be idle.
I ² C_start()	None	None	Issues a START condition.
I ² C_repStart()	None	None	Issues a REPEATED-START condition.
I ² C_stop()	None	None	Issues a STOP condition.
I ² C_read(ack)	ack,	Read data	Enables Receive mode, reads received data from
	acknowledge bit		SSPBUF.
			ack=0, don't acknowledge - ack=1, acknowledge
I ² C_write(I ² CWriteData)	I ² CWriteData,	1 if ACK	Loads data to be transmitted to the slave, into the
	byte to be		SSPBUF.
	transmitted	0 if NACK	and returns a '1' if transmission acknowledged.
write_to_MCP(address,cmd	Start,address,	None	Implements a full write sequence from START to
,data1,data2)	Command,		STOP.
	Data1,		
	Data2,Stop		
GetNewValue()	None	None	Reads value from slave and displays it on
interrunt ing()	Nana	Nama	
	None	None	Interrupt service routine for CCP module.
Check_CCP_status()	None	None	Checks if a CCP interrupt occurred and, if so, calls <i>GetNewValue()</i> .
DelayUs(x)	x = # of µs	None	Delay in microseconds (used in Delay.c only).
DelayUsx(x)	x = # of µs	None	Delay in microseconds with x = number of microseconds.
DelayMs(x)	x = # of msec.	None	Delay in milliseconds with x = number of milliseconds.
DelaySec(x)	x = # of sec.	None	Delay in seconds with x = number of seconds.

TABLE 2: FUNCTIONS USED IN THE SOURCE CODE



FIGURE 14: GETNEWVALUE() SUB-ROUTINE FLOWCHART



TEST BOARD

See Appendix A for a complete schematic diagram of the test board.

SUMMARY

When more I/O ports are needed by a microcontroller (e.g., keyboard, sensors, LEDs, relays, high-side MOS-FET load-switch drivers, etc.), the MCP23016 is a low-cost, simple solution. The Master Synchronous Serial Port (MSSP) embedded on the PIC16F877A, and many of the PICmicro[®] devices, provide I²C communication for use with the MCP23016 16-bit I/O Expander.

This application note demonstrates how to interface the MCP23016 with the PIC16F877A, how the device protocol functions and how to implement it in software. The code used in this application note will work with any PICmicro microcontroller containing an MSSP module. Some code modification may be necessary. The MCP23016 is also compatible with other MCUs that have I²C modules. The test board example (Appendix A) helps in testing and understanding the way the MCP23016 I/O Expander works.

APPENDIX A

I/O EXPANDER TEST BOARD

INTRODUCTION

The I/O Expander test board is equipped with a Microchip MCP23016 I²C I/O Expander slave device connected to the I²C port and the interrupt pin (SDA, SCL, and INT) of the PIC16F877A, which is configured as an I²C master.

Inputs / Outputs

MCP23016

The MCP23016 has 16 bidirectional I/Os (GP0.0-GP0.7 and GP1.0-GP1.7). Pins GP0.0 to GP0.7 are connected to LEDs D1 through D8 and Switch S1. Pins GP1.0 to GP1.7 are connected to LEDs D9 through D16 and Switch S3. This configuration allows the use of the pins as either inputs or outputs. The only drawback with this configuration is that it makes the I/O pins active low for both inputs and outputs (refer to Figure 16 and Figure 17). However, this scheme makes it more convenient for testing. All the pins have 4.7 k Ω pull-up resistors (RP1 and RP2).

FIGURE 15: TEST BOARD CONNECTIONS



PIC16F877A

The PIC16F877A is connected to LEDs in a similar fashion to the MCP23016. PORTB is used as the LSB and is connected to LEDs D17 through D24 and switch S4. PORTD is used as the MSB and is connected to LEDs D25 through D32 and switch S6.

ADDRESS PINS

The MCP23016 has three hardware address pins that are used to allow up to eight MCP23016 devices on the same I^2C bus. The MCP23016 address pins are connected to switch S2. This is done for testing purposes to allow change of addresses using the switch. These pins can be tied permanently high or low.

INTERRUPT PIN

The interrupt pin from the MCP23016 is tied to the capture input pin of the PIC16F877A (RC1/CCP2) and is pulled high using a 1 k Ω resistor (R98).

I²C PINS

The l^2C pins (SDA and SCL) from all devices (U1 and U2) are connected together to form the l^2C bus. Both SDA and SCL are pulled high using two 4.7 k Ω resistors (R100 and R101).









APPENDIX B

I/O EXPANDER INTERFACE CODE

Master Firmware

The master firmware initializes the variables, ports, A/D module, I^2C module and CCP module of the PIC16F877A, then waits for the MCP23016 Power-On-Reset to initialize the I/O Expanders registers. The code enters an infinite loop which checks if a CCP2 interrupt has occurred, then transmits two bytes ("i" and "j") which implement an "LED chaser" type of pattern.

If an interrupt occurs, the code jumps to the interrupt subroutine which clears the CCP2 interrupt flag (CCP2IF=0) and sets a software flag (Flags=0x01) so that the interrupt can be serviced later. When the *Check_CCP_status()* routine is called, it checks the software flag. If the software flag is clear, the code returns to the "main". If the software flag is set, the code jumps to *GetNewValue()* routine which reads the port values from the slave device and displays the read values on PORTB (LSB) and PORTD (MSB).

The firmware is setup to read from and write to the same address. It is possible to have the MCP23016 connected with another I/O Expander device on the same address and write to both of them at the same time. A second MCP23016 with a different address can be added with some code modification.

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products.

Information contained in this publication regarding device applications and the like is intended through suggestion only and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. No representation or warranty is given and no liability is assumed by Microchip Technology Incorporated with respect to the accuracy or use of such information, or infringement of patents or other intellectual property rights arising from such use or otherwise. Use of Microchip's products as critical components in life support systems is not authorized except with express written approval by Microchip. No licenses are conveyed, implicitly or otherwise, under any intellectual property rights.

Trademarks

The Microchip name and logo, the Microchip logo, KEELOQ, MPLAB, PIC, PICmicro, PICSTART, PRO MATE and PowerSmart are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, microID, MXDEV, MXLAB, PICMASTER, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Accuron, dsPIC, dsPICDEM.net, ECONOMONITOR, FanSense, FlexROM, fuzzyLAB, In-Circuit Serial Programming, ICSP, ICEPIC, microPort, Migratable Memory, MPASM, MPLIB, MPLINK, MPSIM, PICC, PICkit, PICDEM, PICDEM.net, PowerCal, PowerInfo, PowerTool, rfPIC, Select Mode, SmartSensor, SmartShunt, SmartTel and Total Endurance are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

Serialized Quick Turn Programming (SQTP) is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2003, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.





Microchip received QS-9000 quality system certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona in July 1999 and Mountain View, California in March 2002. The Company's quality system processes and procedures are QS-9000 compliant for its PICmicro® 8-bit MCUS, KEELoQ® code hopping devices, Serial EEPROMs, microperipherals, non-volatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001 certified.



WORLDWIDE SALES AND SERVICE

AMERICAS

Corporate Office 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: 480-792-7627 Web Address: http://www.microchip.com

Rocky Mountain

2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7966 Fax: 480-792-4338

Atlanta

3780 Mansell Road, Suite 130 Alpharetta, GA 30022 Tel: 770-640-0034 Fax: 770-640-0307

Boston

2 Lan Drive, Suite 120 Westford, MA 01886 Tel: 978-692-3848 Fax: 978-692-3821

Chicago

333 Pierce Road, Suite 180 Itasca, IL 60143 Tel: 630-285-0071 Fax: 630-285-0075

Dallas

4570 Westgrove Drive, Suite 160 Addison, TX 75001 Tel: 972-818-7423 Fax: 972-818-2924

Detroit

Tri-Atria Office Building 32255 Northwestern Highway, Suite 190 Farmington Hills, MI 48334 Tel: 248-538-2250 Fax: 248-538-2260

Kokomo

2767 S. Albright Road Kokomo, Indiana 46902 Tel: 765-864-8360 Fax: 765-864-8387

Los Angeles

18201 Von Karman, Suite 1090 Irvine, CA 92612 Tel: 949-263-1888 Fax: 949-263-1338

San Jose

Microchip Technology Inc. 2107 North First Street, Suite 590 San Jose, CA 95131 Tel: 408-436-7950 Fax: 408-436-7955

Toronto

6285 Northam Drive, Suite 108 Mississauga, Ontario L4V 1X5, Canada Tel: 905-673-0699 Fax: 905-673-6509

ASIA/PACIFIC

Australia

Microchip Technology Australia Pty Ltd Suite 22, 41 Rawson Street Epping 2121, NSW Australia

Tel: 61-2-9868-6733 Fax: 61-2-9868-6755 China - Beijing

Microchip Technology Consulting (Shanghai) Co., Ltd., Beijing Liaison Office Unit 915 Bei Hai Wan Tai Bldg. No. 6 Chaoyangmen Beidajie Beijing, 100027, No. China Tel: 86-10-85282100 Fax: 86-10-85282104

China - Chengdu

Microchip Technology Consulting (Shanghai) Co., Ltd., Chengdu Liaison Office Rm. 2401-2402, 24th Floor, Ming Xing Financial Tower No 88 TIDU Street Chengdu 610016, China Tel: 86-28-86766200 Fax: 86-28-86766599

China - Fuzhou

Microchip Technology Consulting (Shanghai) Co., Ltd., Fuzhou Liaison Office Unit 28F, World Trade Plaza No. 71 Wusi Road Fuzhou 350001, China Tel: 86-591-7503506 Fax: 86-591-7503521

China - Hong Kong SAR

Microchip Technology Hongkong Ltd. Unit 901-6, Tower 2, Metroplaza 223 Hing Fong Road Kwai Fong, N.T., Hong Kong Tel: 852-2401-1200 Fax: 852-2401-3431

China - Shanghai

Microchip Technology Consulting (Shanghai) Co., Ltd. Room 701, Bldg. B Far East International Plaza No. 317 Xian Xia Road Shanghai, 200051 Tel: 86-21-6275-5700 Fax: 86-21-6275-5060 China - Shenzhen Microchip Technology Consulting (Shanghai) Co., Ltd., Shenzhen Liaison Office Rm. 1812, 18/F, Building A, United Plaza No. 5022 Binhe Road, Futian District

Shenzhen 518033, China Tel: 86-755-82901380 Fax: 86-755-82966626

China - Qingdao

Rm. B503, Fullhope Plaza, No. 12 Hong Kong Central Rd. Qingdao 266071, China Tel: 86-532-5027355 Fax: 86-532-5027205 India Microchip Technology Inc. India Liaison Office **Divyasree Chambers** 1 Floor, Wing A (A3/A4) No. 11, O'Shaugnessey Road Bangalore, 560 025, India Tel: 91-80-2290061 Fax: 91-80-2290062

Japan

Microchip Technology Japan K.K. Benex S-1 6F 3-18-20, Shinyokohama Kohoku-Ku, Yokohama-shi Kanagawa, 222-0033, Japan Tel: 81-45-471- 6166 Fax: 81-45-471-6122 Korea Microchip Technology Korea 168-1, Youngbo Bldg. 3 Floor Samsung-Dong, Kangnam-Ku Seoul, Korea 135-882 Tel: 82-2-554-7200 Fax: 82-2-558-5934 Singapore Microchip Technology Singapore Pte Ltd. 200 Middle Road #07-02 Prime Centre Singapore, 188980 Tel: 65-6334-8870 Fax: 65-6334-8850 Taiwan Microchip Technology (Barbados) Inc., Taiwan Branch 11F-3, No. 207 Tung Hua North Road Taipei, 105, Taiwan Tel: 886-2-2717-7175 Fax: 886-2-2545-0139 FUROPE Austria Microchip Technology Austria GmbH Durisolstrasse 2 A-4600 Wels Austria Tel: 43-7242-2244-399 Fax: 43-7242-2244-393 Denmark Microchip Technology Nordic ApS Regus Business Centre Lautrup hoj 1-3 Ballerup DK-2750 Denmark Tel: 45 4420 9895 Fax: 45 4420 9910 France Microchip Technology SARL Parc d'Activite du Moulin de Massy 43 Rue du Saule Trapu Batiment A - ler Etage 91300 Massy, France Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79 Germany Microchip Technology GmbH Steinheilstrasse 10 D-85737 Ismaning, Germany Tel: 49-89-627-144 0 Fax: 49-89-627-144-44 Italy Microchip Technology SRL Centro Direzionale Colleoni Palazzo Taurus 1 V. Le Colleoni 1 20041 Agrate Brianza Milan, Italy Tel: 39-039-65791-1 Fax: 39-039-6899883 United Kingdom Microchip Ltd. 505 Eskdale Road Winnersh Triangle Wokingham Berkshire, England RG41 5TU Tel: 44 118 921 5869 Fax: 44-118 921-5820

12/05/02