
Section 11. Charge Time Measurement Unit (CTMU)

HIGHLIGHTS

This section of the manual contains the following major topics:

11.1	Introduction	11-2
11.2	Registers	11-4
11.3	CTMU Operation	11-10
11.4	CTMU Module Initialization	11-12
11.5	Calibrating the CTMU Module	11-12
11.6	Measuring Capacitance with the CTMU	11-21
11.7	Measuring Time with the CTMU Module	11-24
11.8	Creating a Delay with the CTMU Module	11-25
11.9	Measuring On-Chip Temperature with the CTMU	11-26
11.10	Operation During Sleep/Idle Modes	11-27
11.11	Effects of a Reset on CTMU	11-27
11.12	Register Maps	11-28
11.13	Electrical Specifications	11-29
11.14	Related Application Notes	11-30
11.15	Revision History	11-31

Note: This family reference manual section is meant to serve as a complement to device data sheets. Depending on the device variant, this manual section may not apply to all PIC24F devices.

Please consult the note at the beginning of the “**Charge Time Measurement Unit (CTMU)**” chapter in the current device data sheet to check whether this document supports the device you are using.

Device data sheets and family reference manual sections are available for download from the Microchip Worldwide Web site at: <http://www.microchip.com>

11.1 INTRODUCTION

The Charge Time Measurement Unit (CTMU) is a flexible analog module that provides accurate differential time measurement between pulse sources, as well as asynchronous pulse generation. By working with other on-chip analog modules, the CTMU can be used to precisely measure time, measure capacitance, measure relative changes in capacitance or generate output pulses with a specific time delay. The CTMU is ideal for interfacing with capacitive-based sensors.


The module includes the following key features:

- Up to 16 channels available for capacitive or time measurement input
- On-chip precision current source
- Four-edge input trigger sources
- Polarity control for each edge source
- Control of edge sequence
- Control of response to edges
- High precision time measurement
- Time delay of external or internal signal asynchronous to system clock

The CTMU works in conjunction with the A/D Converter to provide up to 16 channels for time or charge measurement, depending on the specific device and the number of A/D channels available. When configured for time delay, the CTMU is connected to one of the analog comparators. The level-sensitive input edge sources can be selected from four sources: two external inputs, Timer1 or Output Compare Module 1. For device-specific information on available input sources, refer to the appropriate PIC24F data sheet.

A block diagram of the CTMU is shown in Figure 11-1.

Figure 11-1: CTMU Block Diagram



PIC24F Family Reference Manual

11.2 REGISTERS

Depending on the device variant, there are up to three control registers available for the CTMU: CTMUCON and CTMUICON or CMTUCON1, CTMUCON2 and CTMUICON.

The CTMUCON, CTMUCON1 and CTMUCON2 registers (Register 11-1 through Register 11-3) contain control bits for configuring the CTMU module edge source selection, edge source polarity selection, edge sequencing, A/D trigger, analog circuit capacitor discharge and enables. The CTMUICON register (Register 11-4) has bits for selecting the current source range and current source trim.

Register 11-1: CTMUCON: CTMU Control Register

R/W-0	U-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
CTMUEN	—	CTMUSIDL	TGEN	EDGEN	EDGSEQEN	IDISSEN	CTTRIG
bit 15							bit 8

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
EDG2POL	EDG2SEL1 ⁽¹⁾	EDG2SEL0 ⁽¹⁾	EDG1POL	EDG1SEL1 ⁽¹⁾	EDG1SEL0 ⁽¹⁾	EDG2STAT	EDG1STAT
bit 7							bit 0

Legend:

R = Readable bit	W = Writable bit	U = Unimplemented bit, read as '0'
-n = Value at POR	'1' = Bit is set	'0' = Bit is cleared
		x = Bit is unknown

- bit 15 **CTMUEN:** CTMU Enable bit
1 = Module is enabled
0 = Module is disabled
- bit 14 **Unimplemented:** Read as '0'
- bit 13 **CTMUSIDL:** Stop in Idle Mode bit
1 = Discontinue module operation when device enters Idle mode
0 = Continue module operation in Idle mode
- bit 12 **TGEN:** Time Generation Enable bit
1 = Enables edge delay generation
0 = Disables edge delay generation
- bit 10 **EDGEN:** Edge Enable bit
1 = Edges are not blocked
0 = Edges are blocked
- bit 10 **EDGSEQEN:** Edge Sequence Enable bit
1 = Edge 1 event must occur before Edge 2 event can occur
0 = No edge sequence is needed
- bit 9 **IDISSEN:** Analog Current Source Control bit
1 = Analog current source output is grounded
0 = Analog current source output is not grounded
- bit 8 **CTTRIG:** Trigger Control bit
1 = Trigger output is enabled
0 = Trigger output is disabled
- bit 7 **EDG2POL:** Edge 2 Polarity Select bit
1 = Edge 2 programmed for a positive level response
0 = Edge 2 programmed for a negative level response

Note 1: Refer to the particular device data sheet for specific edge source types and assignments.

Register 11-1: CTMUCON: CTMU Control Register (Continued)

- bit 6-5 **EDG2SEL<1:0>**: Edge 2 Source Select bits⁽¹⁾
11 = Edge Source 3 selected
10 = Edge Source 2 selected
01 = Edge Source 1 selected
00 = Edge Source 0 selected
- bit 4 **EDG1POL**: Edge 1 Polarity Select bit
1 = Edge 1 programmed for a positive level response
0 = Edge 1 programmed for a negative level response
- bit 3-2 **EDG1SEL<1:0>**: Edge 1 Source Select bits⁽¹⁾
11 = Edge Source 3 selected
10 = Edge Source 2 selected
01 = Edge Source 1 selected
00 = Edge Source 0 selected
- bit 1 **EDG2STAT**: Edge 2 Status bit
1 = Edge 2 event has occurred
0 = Edge 2 event has not occurred
- bit 0 **EDG1STAT**: Edge 1 Status bit
1 = Edge 1 event has occurred
0 = Edge 1 event has not occurred

Note 1: Refer to the particular device data sheet for specific edge source types and assignments.

PIC24F Family Reference Manual

Register 11-2: CTMUCON1: CTMU Control Register 1⁽¹⁾

R/W-0	U-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
CTMUEN	—	CTMUSIDL	TGEN	EDGEN	EDGSEQEN	IDISSEN	CTTRIG
bit 15							bit 8

U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
—	—	—	—	—	—	—	—
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'
 -n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

- bit 15 **CTMUEN:** CTMU Enable bit
 1 = Module is enabled
 0 = Module is disabled
- bit 14 **Unimplemented:** Read as '0'
- bit 13 **CTMUSIDL:** Stop in Idle Mode bit
 1 = Discontinue module operation when device enters Idle mode
 0 = Continue module operation in Idle mode
- bit 12 **TGEN:** Time Generation Enable bit
 1 = Enables edge delay generation
 0 = Disables edge delay generation
- bit 10 **EDGEN:** Edge Enable bit
 1 = Edges are not blocked
 0 = Edges are blocked
- bit 10 **EDGSEQEN:** Edge Sequence Enable bit
 1 = Edge 1 event must occur before Edge 2 event can occur
 0 = No edge sequence is needed
- bit 9 **IDISSEN:** Analog Current Source Control bit
 1 = Analog current source output is grounded
 0 = Analog current source output is not grounded
- bit 8 **CTTRIG:** Trigger Control bit
 1 = Trigger output is enabled
 0 = Trigger output is disabled
- bit 7-0 **Unimplemented:** Read as '0'

Note 1: Refer to the specific device data sheet to determine whether this register is available on your particular device.

Register 11-3: CTMUCON2: CTMU Control Register 2

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	U-0
EDG1MOD	EDG1POL	EDG1SEL3 ⁽¹⁾	EDG1SEL2 ⁽¹⁾	EDG1SEL1 ⁽¹⁾	EDG1SEL0 ⁽¹⁾	EDG2STAT	EDG1STAT
bit 15							bit 8
R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	U-0	U-0
EDG2MOD	EDG2POL	EDG2SEL3 ⁽¹⁾	EDG2SEL2 ⁽¹⁾	EDG2SEL1 ⁽¹⁾	EDG2SEL0 ⁽¹⁾	—	—
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'
 -n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

- bit 15 **EDG1MOD:** Input mode selection bit
 1 = Input is edge-sensitive
 0 = Input is level-sensitive
- bit 14 **EDG1POL:** Edge 1 Polarity Select bit
 1 = Edge 1 programmed for a positive level response
 0 = Edge 1 programmed for a negative level response
- bit 13-10 **EDG1SEL<3:0>:** Edge 1 Source Select bits⁽¹⁾
 1111 = Edge 1 Source 15 selected
 1110 = Edge 1 Source 14 selected
 1101 = Edge 1 Source 13 selected
 1100 = Edge 1 Source 12 selected
 1011 = Edge 1 Source 11 selected
 1010 = Edge 1 Source 10 selected
 1001 = Edge 1 Source 9 selected
 1000 = Edge 1 Source 8 selected
 0111 = Edge 1 Source 7 selected
 0110 = Edge 1 Source 6 selected
 0101 = Edge 1 Source 5 selected
 0100 = Edge 1 Source 4 selected
 0011 = Edge 1 Source 3 selected
 0010 = Edge 1 Source 2 selected
 0001 = Edge 1 Source 1 selected
 0000 = Edge 1 Source 0 selected
- bit 9 **EDG2STAT:** Edge 2 Status bit
 1 = Edge 2 event has occurred
 0 = Edge 2 event has not occurred
- bit 8 **EDG1STAT:** Edge 1 Status bit
 1 = Edge 1 event has occurred
 0 = Edge 1 event has not occurred
- bit 7 **EDG2MOD:** Input Mode Selection bit
 1 = Input is edge-sensitive
 0 = Input is level-sensitive
- bit 6 **EDG2POL:** Edge 2 Polarity Select bit
 1 = Edge 2 programmed for a positive level response
 0 = Edge 2 programmed for a negative level response

Note 1: Refer to the particular device data sheet for specific edge source types and assignments.

PIC24F Family Reference Manual

Register 11-3: CTMUCON2: CTMU Control Register (Continued)²

bit 5-2 **EDG2SEL<3:0>**: Edge 2 Source Select bits⁽¹⁾

11 = Edge 2 Source 3 selected

10 = Edge 2 Source 2 selected

01 = Edge 2 Source 1 selected

00 = Edge 2 Source 0 selected

bit 1-0 **Unimplemented**: Read as '0'

Note 1: Refer to the particular device data sheet for specific edge source types and assignments.

Register 11-4: CTMUICON: CTMU Current Control Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
ITRIM5	ITRIM4	ITRIM3	ITRIM2	ITRIM1	ITRIM0	IRNG1	IRNG0
bit 15							bit 8
U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
—	—	—	—	—	—	—	—
bit 7							bit 0

Legend:

R = Readable bit

W = Writable bit

U = Unimplemented bit, read as '0'

-n = Value at POR

'1' = Bit is set

'0' = Bit is cleared

x = Bit is unknown

- bit 15-10 **ITRIM<5:0>**: Current Source Trim bits
011111 = Maximum positive change from nominal current
011110
•
•
•
000001 = Minimum positive change from nominal current
000000 = Nominal current output specified by IRNG1:IRNG0
111111 = Minimum negative change from nominal current
•
•
•
100010
100001 = Maximum negative change from nominal current
- bit 9-8 **IRNG<1:0>**: Current Source Range Select bits
11 = 100 × base current
10 = 10 × base current
01 = Base current level (0.55 μA nominal)
00 = Current source disabled or 1000 × base current⁽¹⁾
- bit 7-0 **Unimplemented**: Read as '0'

Note 1: Refer to the specific device data sheet to determine which setting is available on your particular device.

11.3 CTMU OPERATION

The CTMU works by using a fixed current source to charge a circuit. The type of circuit depends on the type of measurement being made. In the case of charge measurement, the current is fixed and the amount of time the current is applied to the circuit is fixed. The amount of voltage read by the A/D is then a measurement of the capacitance of the circuit. In the case of time measurement, the current, as well as the capacitance of the circuit, is fixed. In this case, the voltage read by the A/D is then representative of the amount of time elapsed from the time the current source starts and stops charging the circuit.

If the CTMU is being used as a time delay, both capacitance and current source are fixed, as well as the voltage supplied to the comparator circuit. The delay of a signal is determined by the amount of time it takes the voltage to charge to the comparator threshold voltage.

11.3.1 Theory of Operation

The operation of the CTMU is based on the equation for charge, as shown in Equation 1.

Equation 11-1:

$$I = C \cdot \frac{dV}{dT}$$

More simply, the amount of charge measured in coulombs in a circuit is defined as current in amperes (I) multiplied by the amount of time in seconds that the current flows (t). Charge is also defined as the capacitance in farads (C) multiplied by the voltage of the circuit (V), as shown in Equation 11-2.

Equation 11-2:

$$I \cdot t = C \cdot V$$

The CTMU module provides a constant, known current source. The A/D Converter is used to measure (V) in the equation, leaving two unknowns: capacitance (C) and time (t). Equation 11-2 can be used to calculate capacitance or time, by either the relationship shown in Equation 11-3 and using the known fixed capacitance of the circuit, or by Equation 11-4 using a fixed time that the current source is applied to the circuit.

Equation 11-3:

$$t = \frac{(C \cdot V)}{I}$$

Equation 11-4:

$$C = \frac{(I \cdot t)}{V}$$

11.3.2 Current Source

At the heart of the CTMU is a precision current source, designed to provide a constant reference for measurements. The level of current is user-selectable across three ranges, or a total of two orders of magnitude, with the ability to trim the output in $\pm 2\%$ increments (nominal). The current range is selected by the IRNG1:0> bits (CTMUICON<9:8>) with a value of '00' representing the lowest range.

Current trim is provided by the ITRIM<5:0> bits (CTMUICON<15:10>). These six bits allow trimming of the current source in steps of approximately 2% per step. Note that half of the range adjusts the current source positively and the other half reduces the current source. A value of '000000' is the neutral position (no change). A value of '100000' is the maximum negative adjustment (approximately -62%) and '011111' is the maximum positive adjustment (approximately +62%).

11.3.3 Edge Selection and Control

CTMU measurements are controlled by edge events occurring on the module's two input channels. Each channel, referred to as Edge 1 and Edge 2, can be configured to receive input pulses from one of the edge input pins (CTEDG1 and CTEDG2), Timer1 or Output Compare Module 1. The input channels are level-sensitive, responding to the instantaneous level on the channel rather than a transition between levels. The inputs are selected using the EDG1SEL and EDG2SEL bit pairs (CTMUCON<3:2> and <6:5> or CTMUCON2<5:2> and <13:9>).

In addition to source, each channel can be configured for event polarity using the EDGE2POL and EDGE1POL bits (CTMUCON<7:4> or CTMUCON2<14:6>). The input channels can also be filtered for an edge event sequence (Edge 1 occurring before Edge 2) by setting the EDGSEQEN bit (CTMUCON<10> or CTMUCON1<10>).

11.3.4 Edge Status

The CTMUCON register also contains two status bits: EDG2STAT and EDG1STAT (CTMUCON<1:0> or CTMUCON2<9:8>). Their primary function is to show if an edge response has occurred on the corresponding channel. The CTMU automatically sets a particular bit when an edge response is detected on its channel. The level-sensitive nature of the input channels also means that the status bits become set immediately if the channel's configuration is changed and is the same as the channel's current state.

The module uses the edge status bits to control the current source output to external analog modules (such as the A/D Converter). Current is only supplied to external modules when only one (but not both) of the status bits is set and shuts current off when both bits are either set or cleared. This allows the CTMU to measure current only during the interval between edges. After both status bits are set, it is necessary to clear them before another measurement is taken. Both bits should be cleared simultaneously, if possible, to avoid re-enabling the CTMU current source.

In addition to being set by the CTMU hardware, the edge status bits can also be set by software. This is also the user's application to manually enable or disable the current source. Setting either one (but not both) of the bits enables the current source. Setting or clearing both bits at once disables the source.

11.3.5 Interrupts

The CTMU sets its interrupt flag (IFS4<13>) whenever the current source is enabled, then disabled. An interrupt is generated only if the corresponding interrupt enable bit (IEC4<13>) is also set. If edge sequencing is not enabled (i.e., Edge 1 must occur before Edge 2), it is necessary to monitor the edge status bits and determine which edge occurred last and caused the interrupt.

11.4 CTMU MODULE INITIALIZATION

The following sequence is a general guideline used to initialize the CTMU module:

1. Select the current source range using the IRNG bits (CTMUICON<9:8>).
2. Adjust the current source trim using the ITRIM bits (CTMUICON<15:10>).
3. Configure the edge input sources for Edge 1 and Edge 2 by setting the EDG1SEL and EDG2SEL bits (CTMUICON<3:2> and <6:5> or CTMUICON2<13:10> and <5:2>).
4. Configure the input polarities for the edge inputs using the EDG1POL and EDG2POL bits (CTMUICON<7:4> or CTMUICON2<14:6>). The default configuration is for negative edge polarity (high-to-low transitions).
5. Enable edge sequencing using the EDGSEQEN bit (CTMUICON<10> or CTMUICON1<10>). By default, edge sequencing is disabled.
6. Select the operating mode (Measurement or Time Delay) with the TGEN bit. The default mode is Time/Capacitance Measurement.
7. Configure the module to automatically trigger an A/D conversion when the second edge event has occurred using the CTTRIG bit (CTMUICON<8> or CTMUICON1<8>). The conversion trigger is disabled by default.
8. Discharge the connected circuit by setting the IDISSEN bit (CTMUICON<9> or CTMUICON1<9>); after waiting a sufficient time for the circuit to discharge, clear IDISSEN.
9. Disable the module by clearing the CTMUEN bit (CTMUICON<15> or CTMUICON1<15>).
10. Clear the Edge Status bits, EDG2STAT and EDG1STAT (CTMUICON<1:0> or CTMUICON2<9:8>).
11. Enable both edge inputs by setting the EDGEN bit (CTMUICON<11> or CTMUICON1<11>).
12. Enable the module by setting the CTMUEN bit.

Depending on the type of measurement or pulse generation being performed, one or more additional modules may also need to be initialized and configured with the CTMU module:

- Edge Source Generation: In addition to the external edge input pins, both Timer1 and the Output Compare/PWM1 module can be used as edge sources for the CTMU.
- Capacitance or Time Measurement: The CTMU module uses the A/D Converter to measure the voltage across a capacitor that is connected to one of the analog input channels.
- Pulse Generation: When generating system clock independent output pulses, the CTMU module uses Comparator 2 and the associated comparator voltage reference.

For specific information on initializing these modules, refer to the applicable “PIC24F Family Reference Manual” section for the appropriate module.

11.5 CALIBRATING THE CTMU MODULE

The CTMU requires calibration for precise measurements of capacitance and time, as well as for accurate time delay. If the application only requires measurement of a relative change in capacitance or time, calibration is usually not necessary. An example of this type of application would include a capacitive touch switch, in which the touch circuit has a baseline capacitance and the added capacitance of the human body changes the overall capacitance of a circuit.

If actual capacitance or time measurement is required, two hardware calibrations must take place: the current source needs calibration to set it to a precise current, and the circuit being measured needs calibration to measure and/or nullify all other capacitance other than that to be measured.

11.5.1 Current Source Calibration

The current source on board the CTMU module has a range of $\pm 62\%$ nominal for each of three current ranges. Therefore, for precise measurements, it is possible to measure and adjust this current source by placing a high precision resistor, R_{CAL} , on the analog channel, AN2. An example circuit is shown in Figure 11-2. The current source measurement is performed using the following steps:


1. Initialize the A/D Converter.
2. Initialize the CTMU by configuring the module for Pulse Generation mode ($TGEN = 1$).
3. Enable the current source by setting $EDG1STAT$ ($CTMUCON<0>$ or $CTMUCON1<8>$).
4. Issue settling time delay.
5. Perform A/D conversion.
6. Calculate the current source current using $I = V/R_{CAL}$, where R_{CAL} is a high precision resistance and V is measured by performing an A/D conversion.

The CTMU current source may be trimmed with the trim bits in $CTMUICON$ using an iterative process to get an exact desired current. Alternatively, the nominal value without adjustment may be used. It may be stored by the software for use in all subsequent capacitive or time measurements.

When the module is configured for pulse generation delay by setting the $TGEN$ bit ($CTMUCON<12>$ or $CTMUCON1<12>$), the internal current source is connected to one of the inputs of Comparator 2. Figure 11-2 shows the external connections for current source calibration, as well as the relationship of the different analog modules required.

To calculate the value for R_{CAL} , the nominal current must be chosen and then the resistance can be calculated. For example, if the A/D Converter reference voltage is 3.3V, use 70% of full scale, or 2.31V as the desired approximate voltage to be read by the A/D Converter. If the range of the CTMU current source is selected to be $0.55 \mu A$, the resistor value needed is calculated as $R_{CAL} = 2.31V/0.55 \mu A$, for a value of 4.2 M Ω . Similarly, if the current source is chosen to be $5.5 \mu A$, R_{CAL} would be 420,000 Ω and 42,000 Ω if the current source is set to 55 μA .

Figure 11-2: CTMU Current Source Calibration Circuit



A value of 70% of full-scale voltage is chosen to make sure that the A/D Converter was in a range that is well above the noise floor. Keep in mind that if an exact current is chosen that is to incorporate the trimming bits from $CTMUICON$, the resistor value of R_{CAL} may need to be adjusted accordingly. R_{CAL} may be also be adjusted to allow for available resistor values. R_{CAL} should be of the highest precision available, keeping in mind the amount of precision needed for the circuit that the CTMU will be used to measure. A recommended minimum would be 0.1% tolerance.

The following examples show one typical method for performing a CTMU current calibration. Example 11-1 shows how to initialize the A/D Converter and the CTMU; this routine is typical for applications using both modules. Example 11-3 shows one method for the actual calibration routine. Note that this method manually triggers the A/D Converter; this is done to demonstrate the entire stepwise process. It is also possible to automatically trigger the conversion by setting the $CTTRIG$ bit ($CTMUCON<8>$ or $CTMUCON1<8>$).

Example 11-1: Setup for CTMU Calibration Routines for Devices with the CTMUCON Register

```
#include "p24Fxxxx.h"

/*****
/* Set up CTMU *****/
*****/

void setup(void)
{ //CTMUCON - CTMU Control register
  CTMUCON = 0x1090; //make sure CTMU is disabled
  // CTMU continues to run when emulator is stopped,CTMU continues
  // to run in Idle mode, Time Generation mode enabled, Edges are
  // blocked. No edge sequence order, Analog current source not
  // grounded, trigger output disabled, Edge2 polarity = positive level,
  // Edge2 source = source 0, Edge1 polarity = positive level,
  // Edge1 source = source 0, Set Edge status bits to zero

  //CTMUICON - CTMU Current Control Register
  CTMUICON = 0x0100; //0.55uA, Nominal - No Adjustment
/*****
/ Set up AD Converter *****/
*****/
  TRISB=0x0004; // Set channel 2 as an input
  AD1PCFG=0x0004; //
  AD1CHS=0x002; // Select the analog channel(2)
  AD1CSSL=0x0000; //

  AD1CON1 = 0x8000; // Turn On A/D Converter, continue in Idle mode,
  // Unsigned fractional format, Clear SAMP bit to
  // start conversion, Sample when SAMP bit is set,
  // sampling on hold
  AD1CON2 = 0x0000; // VR+ = AVDD, V- = AVSS, Don't scan,
  // always use MUX A inputs
  AD1CON3 = 0x0000; // A/D uses system clock, conversion clock = 1xTcy
}
}
```

Example 11-2: Setup for CTMU Calibration Routines for Devices with CTMUCON1 and CTMUCON2 Registers

```

#include "p24Fxxxx.h"

/*****
/ Set up CTMU *****/
/*****/

void setup(void)
{
    //CTMUCON - CTMU Control register
    CTMUCON1 = 0x1000;    //make sure CTMU is disabled
    CTMUCON2 = 0xC0C0;
    // CTMU continues to run when emulator is stopped, CTMU continues
    // to run in idle mode, Time Generation mode enabled, Edges are
    // blocked. No edge sequence order, Analog current source not
    // grounded, trigger output disabled, Edge2 polarity = positive level,
    // Edge2 source = source 0, Edge1 polarity = positive level,
    // Edge1 source = source 0, Set Edge status bits to zero

    //CTMUICON - CTMU Current Control Register
    CTMUICON = 0x0100; // 0.55uA, Nominal - No Adjustment
/*****/
/ Set up AD converter *****/
/*****/
    TRISB = 0x0001;    // Set channel 2 as an input
    AD1PCFG = 0x0001; //
    AD1CHS = 0x002;    // Select the analog channel(2)
    AD1CSSL = 0x0000; //

    AD1CON1 = 0x8000; // Turn On A/D Converter, continue in Idle mode,
                    // Unsigned fractional format, Clear SAMP bit to
                    // start conversion, Sample when SAMP bit is set,
                    // sampling on hold
    AD1CON2 = 0x0000; // VR+ = AVDD, V- = AVSS, Don't scan,
                    // always use MUX A inputs
    AD1CON3 = 0x0000; // A/D uses system clock, conversion clock = 1xTcy
}

```

Example 11-3: Current Calibration Routine for Devices with the CTMUCON Register

```
#include "p24Fxxxx.h"

#define COUNT 500          //@ 8MHz = 125uS.
#define DELAY for(i=0;i<COUNT;i++)
#define RCAL .027          //R value is 4200000 (4.2M)
                          //scaled so that result is in
                          //1/100th of uA
#define ADSCALE 1023      //for unsigned conversion 10 sig bits
#define ADREF 3.3         //Vdd connected to A/D Vr+

int main(void)
{
    int i;
    int j = 0;              //index for loop
    unsigned int Vread = 0;
    double VTot = 0;
    float Vavg=0, Vcal=0, CTMUISrc = 0; //float values stored for calcs

    //assume CTMU and A/D have been setup correctly
    //see Example 11-1 for CTMU & A/D setup
    setup();

    CTMUCONbits.CTMUEN = 1; //Enable the CTMU

    for(j=0;j<10;j++)
    {
        AD1CON1bits.SAMP = 1; //Manual sampling start
        CTMUCONbits.IDISSEN = 1; //drain charge on the circuit
        DELAY; //wait 125us
        CTMUCONbits.IDISSEN = 0; //end drain of circuit

        CTMUCONbits.EDG1STAT = 1; //Begin charging the circuit
        //using CTMU current source
        DELAY; //wait for 125 us

        IFS0bits.ADLIF = 0; //make sure A/D Int not set
        AD1CON1bits.SAMP = 0; //and begin A/D conv.
        while(!IFS0bits.ADLIF); //Wait for A/D convert complete
        AD1CON1bits.DONE = 0;
        CTMUCONbits.EDG1STAT = 0; //Stop charging circuit
        Vread = ADC1BUF0; //Get the value from the A/D
        IFS0bits.ADLIF = 0; //Clear A/D Interrupt Flag
        VTot += Vread; //Add the reading to the total
    }

    Vavg = (float)(VTot/10.000); //Average of 10 readings
    Vcal = (float)(Vavg/ADSCALE*ADREF);
    CTMUISrc = Vcal/RCAL; //CTMUISrc is in 1/100ths of uA
}
```

Example 11-4: Current Calibration Routine for Devices with CTMUCON1 and CTMUCON2 Registers

```

#include "p24Fxxxx.h"

#define COUNT 500          //@ 8MHz = 125uS.
#define DELAY for(i=0;i<COUNT;i++)
#define RCAL .027          //R value is 4200000 (4.2M)
                              //scaled so that result is in
                              //1/100th of uA
#define ADSCALE 1023      //for unsigned conversion 10 sig bits
#define ADREF 3.3         //Vdd connected to A/D Vr+

int main(void)
{
    int i;
    int j = 0;              //index for loop
    unsigned int Vread = 0;
    double VTot = 0;
    float Vavg=0, Vcal=0, CTMUISrc = 0; //float values stored for calcs

    //assume CTMU and A/D have been setup correctly
    //see Example 11-1 for CTMU & A/D setup
    setup();

    CTMUCON1bits.CTMUEN = 1; //Enable the CTMU

    for(j=0;j<10;j++)
    {
        AD1CON1bits.SAMP = 1; //Manual sampling start
        CTMUCON1bits.IDISSEN = 1; //drain charge on the circuit
        DELAY; //wait 125us
        CTMUCON1bits.IDISSEN = 0; //end drain of circuit

        CTMUCON2bits.EDG1STAT = 1; //Begin charging the circuit
        //using CTMU current source
        DELAY; //wait for 125 us

        IFS0bits.ADLIF = 0; //make sure A/D Int not set
        AD1CON1bits.SAMP = 0; //and begin A/D conv.
        while(!IFS0bits.ADLIF); //Wait for A/D convert complete
        AD1CON1bits.DONE = 0;
        CTMUCON2bits.EDG1STAT = 0; //Stop charging circuit
        Vread = ADC1BUF0; //Get the value from the A/D
        IFS0bits.ADLIF = 0; //Clear A/D Interrupt Flag
        VTot += Vread; //Add the reading to the total
    }

    Vavg = (float)(VTot/10.000); //Average of 10 readings
    Vcal = (float)(Vavg/ADSCALE*ADREF);
    CTMUISrc = Vcal/RCAL; //CTMUISrc is in 1/100ths of uA
}

```

11.5.2 Capacitance Calibration

There is a small amount of capacitance from the internal A/D Converter sample capacitor as well as stray capacitance from the circuit board traces and pads that affect the precision of capacitance measurements. A measurement of the stray capacitance can be taken by making sure the desired capacitance to be measured has been removed. The measurement is then performed using the following steps:

1. Initialize the A/D Converter and the CTMU.
2. Set EDG1STAT (= 1).
3. Wait for a fixed delay of time, t .
4. Clear EDG1STAT.
5. Perform an A/D conversion.
6. Calculate the stray and A/D sample capacitances using Equation 11-5.

Equation 11-5:

$$C_{OFFSET} = C_{STRAY} + C_{AD} = \frac{I \cdot t}{V}$$

where I is known from the current source measurement step, t is a fixed delay and V is measured by performing an A/D conversion.

This measured value is then stored and used for calculations of time measurement or subtracted for capacitance measurement. For calibration, it is expected that the capacitance of $C_{STRAY} + C_{AD}$ is approximately known. C_{AD} is approximately 4 pF.

An iterative process may need to be used to adjust the time, t , that the circuit is charged to obtain a reasonable voltage reading from the A/D Converter. The value of t may be determined by setting C_{OFFSET} to a theoretical value, then solving for t . For example, if C_{STRAY} is theoretically calculated to be 11 pF, and V is expected to be 70% of V_{DD} , or 2.31V, t would be equal to Equation 11-6 or 63 μ s.

Equation 11-6: :

$$(4 \text{ pF} + 11 \text{ pF}) \cdot \frac{2.31 \text{ V}}{0.55 \mu\text{A}}$$

A typical routine for CTMU capacitance calibration is shown in Example 11-5.

Example 11-5: Capacitance Calibration Routine for Devices with the CTMUCON Register

```

#include "p24Fxxxx.h"

#define COUNT 25          //@ 8MHz INTFRC = 62.5 us.
#define ETIME COUNT*2.5  //time in uS
#define DELAY for(i=0;i<COUNT;i++)
#define ADSCALE 1023    //for unsigned conversion 10 sig bits
#define ADREF 3.3       //Vdd connected to A/D Vr+

int main(void)
{
    int i;
    int j = 0;           //index for loop
    unsigned int Vread = 0;
    float CTMUISrc, CTMUCap, Vavg, VTot, Vcal;

                                //assume CTMU and A/D have been setup correctly
                                //see Example 11-1 for CTMU & A/D setup
    setup();

    CTMUCONbits.CTMUEN = 1;//Enable the CTMU

    for(j=0;j<10;j++)
    {
        AD1CON1bits.SAMP = 1;    //Manual sampling start
        CTMUCONbits.IDISSEN= 1; //drain any charge on the circuit
        DELAY;                   //wait 62.5 us
        CTMUCONbits.IDISSEN = 0; //end drain of circuit
        CTMUCONbits.EDG1STAT = 1; //Begin charging the circuit
                                //using the CTMU current source
        DELAY;                   //wait for 62.5 us for circuit to charge
        CTMUCONbits.EDG1STAT = 0; //Stop charging circuit and begin A/D conv.
        AD1CON1bits.SAMP = 0;
        while(!IFS0bits.ADLIF); //Wait for A/D conversion to complete
        Vread = ADCLBUF0;       //Get the value from the A/D converter
        IFS0bits.ADLIF = 0;    //Clear ADLIF
        VTot += Vread;         //Add the reading to the total
    }

    Vavg = (VTot/10); //Average of 10 readings
    Vcal = (Vavg/ADSCALE*ADREF);
    CTMUCap = (CTMUISrc*ETIME/Vcal)/100;
    //CTMUISrc is in 1/100ths of uA,
    //calculated in Example 1-2
    //time is in us
    //CTMUCap is in pF
}

```

Example 11-6: Capacitance Calibration Routine for Devices with CTMUCON1 and CTMUCON2 Registers

```
#include "p24Fxxxx.h"

#define COUNT 25          //@ 8MHz INTFRC = 62.5 us.
#define ETIME COUNT*2.5  //time in us
#define DELAY for(i=0;i<COUNT;i++)
#define ADSCALE 1023    //for unsigned conversion 10 sig bits
#define ADREF 3.3       //Vdd connected to A/D Vr+

int main(void)
{
    int i;
    int j = 0;           //index for loop
    unsigned int Vread = 0;
    float CTMUISrc, CTMUCap, Vavg, VTot, Vcal;

                                //assume CTMU and A/D have been setup correctly
                                //see Example 11-1 for CTMU & A/D setup

    setup();

    CTMUCON1bits.CTMUEN = 1;//Enable the CTMU

    for(j=0;j<10;j++)
    {
        AD1CON1bits.SAMP = 1;      //Manual sampling start
        CTMUCON1bits.IDISSEN= 1;   //drain any charge on the circuit
        DELAY;                     //wait 62.5 us
        CTMUCON1bits.IDISSEN = 0;  //end drain of circuit
        CTMUCON2bits.EDG1STAT = 1; //Begin charging the circuit
                                    //using the CTMU current source
        DELAY;                     //wait for 62.5 us for circuit
                                    //to charge
        CTMUCON2bits.EDG1STAT = 0; //Stop charging circuit and begin
                                    //A/D conversion

        AD1CON1bits.SAMP = 0;
        while(!IFS0bits.AD1IF);    //Wait for A/D conversion to complete
        Vread = ADC1BUF0;          //Get the value from the A/D converter
        IFS0bits.AD1IF = 0;       //Clear AD1IF
        VTot += Vread;            //Add the reading to the total
    }

    Vavg = (VTot/10); //Average of 10 readings
    Vcal = (Vavg/ADSCALE*ADREF);
    CTMUCap = (CTMUISrc*ETIME/Vcal)/100;
    //CTMUISrc is in 1/100ths of uA,
    //calculated in Example 1-2
    //time is in us
    //CTMUCap is in pF
}
```

11.6 MEASURING CAPACITANCE WITH THE CTMU

There are two separate methods of measuring capacitance with the CTMU. The first is the absolute method, in which the actual capacitance value is desired. The second is the relative method, in which the actual capacitance is not needed, rather an indication of a change in capacitance is required.

11.6.1 Absolute Capacitance Measurement

For absolute capacitance measurements, both the current and capacitance calibration steps found in **Section 11.5 “Calibrating the CTMU Module”** should be followed. Capacitance measurements are then performed using the following steps:

1. Initialize the A/D Converter.
2. Initialize the CTMU.
3. Set EDG1STAT.
4. Wait for a fixed delay, T .
5. Clear EDG1STAT.
6. Perform an A/D conversion.
7. Calculate the total capacitance, $C_{TOTAL} = (I * T)/V$, where I is known from the current source measurement step (**Section 11.5.1 “Current Source Calibration”**), T is a fixed delay and V is measured by performing an A/D conversion.
8. Subtract the stray and A/D capacitance (C_{OFFSET} from **Section 11.5.2 “Capacitance Calibration”**) from C_{TOTAL} to determine the measured capacitance.

11.6.2 Relative Charge Measurement

An application may not require precise capacitance measurements. For example, when detecting a valid press of a capacitance-based switch, detecting a relative change of capacitance is of interest. In this type of application, when the switch is open (or not touched), the total capacitance is the capacitance of the combination of the board traces, the A/D Converter, etc. A larger voltage will be measured by the A/D Converter. When the switch is closed (or is touched), the total capacitance is larger due to the addition of the capacitance of the human body to the above listed capacitances and a smaller voltage will be measured by the A/D Converter.

Detecting capacitance changes is easily accomplished with the CTMU using these steps:

1. Initialize the A/D Converter and the CTMU.
2. Set EDG1STAT.
3. Wait for a fixed delay.
4. Clear EDG1STAT.
5. Perform an A/D conversion.

The voltage measured by performing the A/D conversion is an indication of the relative capacitance. Note that in this case, no calibration of the current source or circuit capacitance measurement is needed. A sample software routine for a capacitive touch switch is shown in Example 11-7.

Example 11-7: Routine for Capacitive Touch Switch for Devices with the CTMUCON Register

```
#include "p24Fxxxx.h"

#define COUNT 500    //@ 8MHz = 125uS.
#define DELAY for(i=0;i<COUNT;i++)
#define OPENSW 1000 //Unpressed switch value
#define TRIP 300    //Difference between pressed
                    //and unpressed switch
#define HYST 65     //amount to change
                    //from pressed to unpressed

#define PRESSED 1
#define UNPRESSED 0

int main(void)
{
    unsigned int Vread;    //storage for reading
    unsigned int switchState;
    int i;

                                //assume CTMU and A/D have been setup correctly
                                //see Example 11-1 for CTMU & A/D setup

    setup();

    CTMUCONbits.CTMUEN = 1;    //Enable the CTMU

    AD1CON1bits.SAMP = 1;    //Manual sampling start
    CTMUCONbits.IDISSEN = 1; //drain charge on the circuit
    DELAY;                    //wait 125us
    CTMUCONbits.IDISSEN = 0; //end drain of circuit

    CTMUCONbits.EDG1STAT = 1; //Begin charging the circuit
                                //using CTMU current source
    DELAY;                    //wait for 125us
    CTMUCONbits.EDG1STAT = 0; //Stop charging circuit

    IFS0bits.AD1IF = 0;    //make sure A/D Int not set
    AD1CON1bits.SAMP = 0;    //and begin A/D conv.
    while(!IFS0bits.AD1IF); //Wait for A/D convert complete
    AD1CON1bits.DONE = 0;
    Vread = ADC1BUF0;    //Get the value from the A/D
    if(Vread < OPENSW - TRIP)
    {
        switchState = PRESSED;
    }
    else if(Vread > OPENSW - TRIP + HYST)
    {
        switchState = UNPRESSED;
    }
}
}
```

Example 11-8: Routine for Capacitive Touch Switch for Devices with CTMUCON1 and CTMUCON2 Registers

```

#include "p24Fxxxx.h"

#define COUNT 500 // @ 8MHz = 125uS.
#define DELAY for(i=0;i<COUNT;i++)
#define OPENSW 1000 // Unpressed switch value
#define TRIP 300 // Difference between pressed
// and unpressed switch
#define HYST 65 // amount to change
// from pressed to unpressed

#define PRESSED 1
#define UNPRESSED 0

int main(void)
{
    unsigned int Vread; // storage for reading
    unsigned int switchState;
    int i;

    // assume CTMU and A/D have been setup correctly
    // see Example 11-1 for CTMU & A/D setup

    setup();

    CTMUCON1bits.CTMUEN = 1; // Enable the CTMU

    AD1CON1bits.SAMP = 1; // Manual sampling start
    CTMUCON1bits.IDISSEN = 1; // drain charge on the circuit
    DELAY; // wait 125us
    CTMUCON1bits.IDISSEN = 0; // end drain of circuit

    CTMUCON2bits.EDG1STAT = 1; // Begin charging the circuit
    // using CTMU current source
    DELAY; // wait for 125us
    CTMUCON2bits.EDG1STAT = 0; // Stop charging circuit

    IFS0bits.AD1IF = 0; // make sure A/D Int not set
    AD1CON1bits.SAMP = 0; // and begin A/D conv.
    while(!IFS0bits.AD1IF); // Wait for A/D convert complete
    AD1CON1bits.DONE = 0;
    Vread = ADC1BUF0; // Get the value from the A/D
    if(Vread < OPENSW - TRIP)
    {
        switchState = PRESSED;
    }
    else if(Vread > OPENSW - TRIP + HYST)
    {
        switchState = UNPRESSED;
    }
}

```

11.7 MEASURING TIME WITH THE CTMU MODULE

Time can be precisely measured after the ratio (C/I) is measured from the current and capacitance calibration step by following these steps:

1. Initialize the A/D Converter and the CTMU.
2. Set EDG1STAT.
3. Set EDG2STAT.
4. Perform an A/D conversion.
5. Calculate the time between edges as $T = (C/I) * V$, where I is calculated in the current calibration step (**Section 11.5.1 “Current Source Calibration”**), C is calculated in the capacitance calibration step (**Section 11.5.2 “Capacitance Calibration”**) and V is measured by performing the A/D conversion.

It is assumed that the time measured is small enough that the capacitance, C_{OFFSET} , provides a valid voltage to the A/D Converter. For the smallest time measurement, always set the A/D Channel Select register (AD1CHS) to an unused A/D channel; the corresponding pin for which is not connected to any circuit board trace. This minimizes added stray capacitance, keeping the total circuit capacitance close to that of the A/D Converter itself (4-5 pF). To measure longer time intervals, an external capacitor may be connected to an A/D channel and this channel selected when making a time measurement.

11.8 CREATING A DELAY WITH THE CTMU MODULE

A unique feature on board the CTMU module is its ability to generate system clock independent output pulses based on an external capacitor value. This is accomplished using the internal comparator voltage reference module, Comparator 2 input pin and an external capacitor. The pulse is output onto the CTPLS pin. To enable this mode, set the TGEN bit.


An example circuit is shown in Figure 11-3. C_{PULSE} is chosen by the user to determine the output pulse width on CTPLS. The pulse width is calculated by $T = (C_{PULSE}/I) * V$, where I is known from the current source measurement step (**Section 11.5.1 “Current Source Calibration”**) and V is the internal reference voltage (CVREF).

An example use of this feature is for interfacing with variable capacitive-based sensors, such as a humidity sensor. As the humidity varies, the pulse-width output on CTPLS will vary. The CTPLS output pin can be connected to an input capture pin and the varying pulse width is measured to determine the humidity in the application.

Follow these steps to use this feature:

1. Initialize Comparator 2.
2. Initialize the comparator voltage reference.
3. Initialize the CTMU and enable time delay generation by setting the TGEN bit.
4. Set EDG1STAT.
5. When C_{PULSE} charges to the value of the voltage reference trip point, an output pulse is generated on CTPLS.

Figure 11-3: Typical Connections and Internal Configuration for Pulse Delay Generation




11.9 MEASURING ON-CHIP TEMPERATURE WITH THE CTMU

Note: This feature is available only on devices with CTMUCON1 and CTMUCON2 registers. Please refer to the specific data sheet to ensure this feature is available.

The CTMU module can be used to measure the internal temperature of the device through an internal diode that is available for such purposes. When EDGE1 is not equal to EDGE2 and TGEN = 0, the current is steered into the temperature sensing diode. The voltage across the diode is available as an input to the ADC module (AN13).

Figure 11-4 shows how this module can be used for temperature measurement. As the temperature rises, the voltage across the diode will drop by about 300 mV over a 150°C range. Selecting a higher current drive strength will raise the voltage value by a few 100 mV.

Figure 11-4: CTMU Temperature Measurement Circuit



At 25°C, the forward voltage of the temperature diode is 0.83V. The rate of change between the forward voltage of the diode and its temperature is 1.87 mV per degree Celsius. The formula shown in Equation 11-7 can be used to calculate the forward voltage.

Equation 11-7: Voltage versus Temperature

$$V_f \text{ (in mV)} = 783.24mV + 1.87mV \cdot T$$

Where,

V_f = Forward voltage of temperature diode

T = Temperature in degrees Celsius

11.10 OPERATION DURING SLEEP/IDLE MODES

11.10.1 Sleep Mode and Deep Sleep Modes

When the device enters any Sleep mode, the CTMU module current source is always disabled. If the CTMU is performing an operation that depends on the current source when Sleep mode is invoked, the operation may not terminate correctly. Capacitance and time measurements may return erroneous values.

11.10.2 Idle Mode

The behavior of the CTMU in Idle mode is determined by the CTMUSIDL bit (CTMUCON<13> or CTMUCON1<13>). If CTMUSIDL is cleared, the module will continue to operate in Idle mode. If CTMUSIDL is set, the module's current source is disabled when the device enters Idle mode. If the module is performing an operation when Idle mode is invoked, in this case, the results will be similar to those with Sleep mode.

11.11 EFFECTS OF A RESET ON CTMU

Upon Reset, all registers of the CTMU are cleared. This leaves the CTMU module disabled, its current source is turned off and all configuration options return to their default settings. The module needs to be re-initialized following any Reset.

If the CTMU is in the process of taking a measurement at the time of Reset, the measurement will be lost. A partial charge may exist on the circuit that was being measured and should be properly discharged before the CTMU makes subsequent attempts to make a measurement. The circuit is discharged by setting and then clearing the IDISSEN bit (CTMUCON<9> or CTMUCON1<9>) while the A/D Converter is connected to the appropriate channel.

11.12 REGISTER MAPS

A summary of the registers associated with the PIC24F CTMU is provided in Table 11-1.

Table 11-1: CTMU Register Map

File Name	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	All Resets
CTMUCON	CTMUEN	—	CTMUSIDL	TGEN	EDGEN	EDGSEQEN	IDISSEN	CTTRIG	EDG2POL	EDG2SEL<1:0>		EDG1POL	EDG1SEL<1:0>		EDG2STAT	EDG1STAT	0000
CTMUCON1 ⁽¹⁾	CTMUEN	—	CTMUSIDL	TGEN	EDGEN	EDGSEQEN	IDISSEN	CTTRIG	—	—	—	—	—	—	—	—	0000
CTMUCON2 ⁽¹⁾	EDG1MOD	EDG1POL	EDG1SEL3	EDG1SEL2	EDG1SEL1	EDG1SEL0	EDG2STAT	EDG1STAT	EDG2MOD	EDG2POL	EDG2SEL3	EDG2SEL2	EDG2SEL1	EDG2SEL0	—	—	0000
CTMUICON	ITRIM5	ITRIM4	ITRIM3	ITRIM2	ITRIM1	ITRIM0	IRNG1	IRNG0	—	—	—	—	—	—	—	—	0000

Legend: — = unimplemented, read as '0'. Reset values are shown in hexadecimal.

Note 1: Refer to the specific device data sheet to determine whether this register is available on your particular device.

11.13 ELECTRICAL SPECIFICATIONS

Table 11-2: CTMU Current Source Specifications

DC CHARACTERISTICS			Standard Operating Conditions: 2.0V to 3.6V (unless otherwise stated) Operating temperature $-40^{\circ}\text{C} \leq T_A \leq +85^{\circ}\text{C}$ for Industrial				
Param No.	Sym	Characteristic	Min	Typ ⁽¹⁾	Max	Units	Conditions
	IOUT1	CTMU Current Source, Base Range	—	550	—	nA	CTMUICON<1:0> = 01
	IOUT2	CTMU Current Source, 10x Range	—	5.5	—	μA	CTMUICON<1:0> = 10
	IOUT3	CTMU Current Source, 100x Range	—	55	—	μA	CTMUICON<1:0> = 11

Note 1: Nominal value at center point of current trim range (CTMUICON<7:2> = 000000).

11.14 RELATED APPLICATION NOTES

This section lists application notes that are related to this section of the manual. These application notes may not be written specifically for the PIC24F device family, but the concepts are pertinent and could be used with modification and possible limitations. The current application notes related to the CTMU module are:

Title	Application Note #
No related application notes at this time.	

Note: Please visit the Microchip web site (www.microchip.com) for additional application notes and code examples for the PIC24F family of devices.
--

11.15 REVISION HISTORY

Revision A (March 2008)

This is the initial released revision of this document.

Revision B (May 2010)

This revision includes the following updates:

- Updated the CTMU Block Diagram (Figure 11-1) to include the new registers, CTMUCON1 and CTMUCON2, and added Note 1
- Updated the introductory paragraphs in **Section 11.2 “Registers”** to include references to the new registers
- Added the CTMU Control Register 1 (Register 11-2) and the CTMU Control Register 2 (Register 11-3)
- Updated the bit setting definition for IRNG<1:0> = 00 in the CTMU Current Control Register (Register 11-4)
- Updated the charge equation (Equation 11-1) in **Section 11.3.1 “Theory of Operation”**
- Updated the CTMU Current Source Calibration Circuit (see Figure 11-2)
- Updated existing examples and added new examples for the CTMUCON1 and CTMUCON2 registers. Example titles have been updated to reflect the register or registers to which the code is applicable. See Example 11-1 through Example 11-8.
- Updated the Typical Connections and Internal Configuration for Pulse Delay Generation (Example 11-3) and added Note 1
- Added the new section **Section 11.9 “Measuring On-Chip Temperature with the CTMU”**
- Added the new registers, CTMUCON1 and CTMUCON2, to the register map and added Note 1 (see Table 11-1)

PIC24F Family Reference Manual

NOTES:

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

Trademarks

The Microchip name and logo, the Microchip logo, dsPIC, KEELOQ, KEELOQ logo, MPLAB, PIC, PICmicro, PICSTART, PIC³² logo, rPIC and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MXDEV, MXLAB, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Octopus, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICkit, PICtail, REAL ICE, rLAB, Select Mode, Total Endurance, TSHARC, UniWinDriver, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2010, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

 Printed on recycled paper.

ISBN:978-1-60932-236-6

Microchip received ISO/TS-16949:2002 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

**QUALITY MANAGEMENT SYSTEM
CERTIFIED BY DNV
== ISO/TS 16949:2002 ==**



WORLDWIDE SALES AND SERVICE

AMERICAS

Corporate Office
2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7200
Fax: 480-792-7277
Technical Support:
<http://support.microchip.com>
Web Address:
www.microchip.com

Atlanta
Duluth, GA
Tel: 678-957-9614
Fax: 678-957-1455

Boston
Westborough, MA
Tel: 774-760-0087
Fax: 774-760-0088

Chicago
Itasca, IL
Tel: 630-285-0071
Fax: 630-285-0075

Cleveland
Independence, OH
Tel: 216-447-0464
Fax: 216-447-0643

Dallas
Addison, TX
Tel: 972-818-7423
Fax: 972-818-2924

Detroit
Farmington Hills, MI
Tel: 248-538-2250
Fax: 248-538-2260

Kokomo
Kokomo, IN
Tel: 765-864-8360
Fax: 765-864-8387

Los Angeles
Mission Viejo, CA
Tel: 949-462-9523
Fax: 949-462-9608

Santa Clara
Santa Clara, CA
Tel: 408-961-6444
Fax: 408-961-6445

Toronto
Mississauga, Ontario,
Canada
Tel: 905-673-0699
Fax: 905-673-6509

ASIA/PACIFIC

Asia Pacific Office
Suites 3707-14, 37th Floor
Tower 6, The Gateway
Harbour City, Kowloon
Hong Kong
Tel: 852-2401-1200
Fax: 852-2401-3431

Australia - Sydney
Tel: 61-2-9868-6733
Fax: 61-2-9868-6755

China - Beijing
Tel: 86-10-8528-2100
Fax: 86-10-8528-2104

China - Chengdu
Tel: 86-28-8665-5511
Fax: 86-28-8665-7889

China - Chongqing
Tel: 86-23-8980-9588
Fax: 86-23-8980-9500

China - Hong Kong SAR
Tel: 852-2401-1200
Fax: 852-2401-3431

China - Nanjing
Tel: 86-25-8473-2460
Fax: 86-25-8473-2470

China - Qingdao
Tel: 86-532-8502-7355
Fax: 86-532-8502-7205

China - Shanghai
Tel: 86-21-5407-5533
Fax: 86-21-5407-5066

China - Shenyang
Tel: 86-24-2334-2829
Fax: 86-24-2334-2393

China - Shenzhen
Tel: 86-755-8203-2660
Fax: 86-755-8203-1760

China - Wuhan
Tel: 86-27-5980-5300
Fax: 86-27-5980-5118

China - Xian
Tel: 86-29-8833-7252
Fax: 86-29-8833-7256

China - Xiamen
Tel: 86-592-2388138
Fax: 86-592-2388130

China - Zhuhai
Tel: 86-756-3210040
Fax: 86-756-3210049

ASIA/PACIFIC

India - Bangalore
Tel: 91-80-3090-4444
Fax: 91-80-3090-4123

India - New Delhi
Tel: 91-11-4160-8631
Fax: 91-11-4160-8632

India - Pune
Tel: 91-20-2566-1512
Fax: 91-20-2566-1513

Japan - Yokohama
Tel: 81-45-471- 6166
Fax: 81-45-471-6122

Korea - Daegu
Tel: 82-53-744-4301
Fax: 82-53-744-4302

Korea - Seoul
Tel: 82-2-554-7200
Fax: 82-2-558-5932 or
82-2-558-5934

Malaysia - Kuala Lumpur
Tel: 60-3-6201-9857
Fax: 60-3-6201-9859

Malaysia - Penang
Tel: 60-4-227-8870
Fax: 60-4-227-4068

Philippines - Manila
Tel: 63-2-634-9065
Fax: 63-2-634-9069

Singapore
Tel: 65-6334-8870
Fax: 65-6334-8850

Taiwan - Hsin Chu
Tel: 886-3-6578-300
Fax: 886-3-6578-370

Taiwan - Kaohsiung
Tel: 886-7-536-4818
Fax: 886-7-536-4803

Taiwan - Taipei
Tel: 886-2-2500-6610
Fax: 886-2-2508-0102

Thailand - Bangkok
Tel: 66-2-694-1351
Fax: 66-2-694-1350

EUROPE

Austria - Wels
Tel: 43-7242-2244-39
Fax: 43-7242-2244-393

Denmark - Copenhagen
Tel: 45-4450-2828
Fax: 45-4485-2829

France - Paris
Tel: 33-1-69-53-63-20
Fax: 33-1-69-30-90-79

Germany - Munich
Tel: 49-89-627-144-0
Fax: 49-89-627-144-44

Italy - Milan
Tel: 39-0331-742611
Fax: 39-0331-466781

Netherlands - Drunen
Tel: 31-416-690399
Fax: 31-416-690340

Spain - Madrid
Tel: 34-91-708-08-90
Fax: 34-91-708-08-91

UK - Wokingham
Tel: 44-118-921-5869
Fax: 44-118-921-5820