USING PICKIT BEBUGGER



Install the MPLAB® IDE software onto your PC using the MPLAB IDE CD-ROM or download the software from the MPLAB IDE page of the Microchip web site (www.microchip.com/MPLAB). Check the latest Release Notes for additional information.



Connect the PICkit™ 3 in-circuit development debugger/programmer to a PC USB port via a USB cable. PICkit 3 uses the standard HID USB Windows® driver.

Note: If a USB hub is used, the hub must be powered with its own power supply.



B Build Your Project

- 1. Launch MPLAB IDE.
- 2. Load your project or use the Project Wizard to create a new one.
- 3. Build your project based on your configurations and options.
- 4. Select the PICkit 3 as either a debugger (<u>Debugger>Select Tool>PICkit 3</u>) or as a programmer (<u>Programmer>Select Programmer>PICkit 3</u>).


Connect to Target and Power

- 1. Attach the PICkit 3 to the PC using the USB cable, if not already.
- 2. Attach the communications cable between the debugger and target board.
- 3. Connect power to the target board.

Typical Debugger System – Device With On-Board ICE Circuitry:



Alternate Debugger System - ICE Device:




6 Program and Debug

- 1. Program your device.
- 2. As a programmer, PICkit 3 will automatically run your code. As a debugger, you can run, halt, single step and set breakpoints in your code.

Note: For information on reserved resouces used by the debugger, see the PICkit 3 online help.


ADDITIONAL INFORMATION

Circuitry and Connector Pinouts



*Target device must be running with an oscillator for the debugger to function as a debugger.

Target Circuit Design Precautions



Target Application PC Board

- Do not use greater than 100 μF capacitance on Vpp depending on the overall load, it will prevent the target from powering quickly when PICkit 3 is the source of power.
- Do not use capacitors on MCLR they will prevent fast transitions of VPP.
- Do not use pull-ups on PGC/PGD they will divide the voltage levels since these lines have 4.7 kΩ pull-down resistors in PICkit 3.
- Do not use multiplexing on PGC/PGD they are dedicated for communications to PICkit 3.
- Do not use capacitors on PGC/PGD they will prevent fast transitions on data and clock lines during
- programming and debug communications.
 Do not use diodes on PGC/PGD they will prevent bidirectional communication between PICkit 3 and the target PIC® MCI.

Recommended Settings

| COMPONENT | SETTING |
|--------------------|-----------------------------|
| Oscillator | OSC bits set properly |
| | Running |
| Power | Supplied by target |
| WDT | Disabled (device dependent) |
| Code Protect | Disabled |
| Table Read Protect | Disabled |
| LVP | Disabled |
| BOD | VDD > BOD VDD min |
| JTAG | Disabled |
| AVDD and AVss | Must be connected |
| PGCx/PGDx | Proper channel selected, if |
| | applicable |
| Programming | VDD voltage levels meet |
| | programming specs |

Note: See the *PICkit 3 User's Guide* for more component and setting information.

The Microchip name and logo, the Microchip logo, MPLAB and PIC are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries. PICkit is a trademark of Microchip Technology Incorporated in the U.S.A. and other countries.

© 2010 Microchip Technology Incorporated. All Rights Reserved. 4/10





^{**}If the device has AVDD and AVss lines, they must be connected for the debugger to operate.